

Care of your Odyssey fabric boat cover

Odyssey™ Care

Odyssey™ fabric is finished to resist the growth of mildew. However, accumulations of dirt and animal droppings which can support growth of mildew and result in fabric staining, should be removed periodically by recommended cleaning methods.

The boat cover should not be folded and stored while wet.

Odyssey™ Cleaning

Odyssey™ fabric may be cleaned with mild soap and warm (100° F) water.

Do NOT use detergents.*

Use a soft, bristled brush to lift soil embedded in the fabric surface. Rinse thoroughly with clear water to remove soil and soap residue.

After thorough cleaning and drying, water repellency may be reduced. The water repellency can be improved by an application of Aqua-Tite® Green water repellent.

* A detergent is a surfactant or a mixture of surfactants with cleaning properties in dilute solutions. These substances are usually alkylbenzenesulfonates, a family of compounds that are similar to soap but are more soluble in hard water. (Wikipedia)